

適合表 【充電器~その他】
[検索画面に戻る](#)

機種名	型番	充電端子		Qi	USBソケットのみ		Lightning	TypeC		Micro USB		マルチタイプ																
		DC			AC	ケーブルのみ		DC	AC	DC		ケーブルのみ	DC	ケーブルのみ	DC													
		ケーブル	USBポート		付属なし(純正ケーブル使用)	wireless	LT↔A	LT固定	LT↔A	LT固定	CeA	CeC	A+CeC	C固定	CeA	M-B+A	M-B+A	M-B固定	M-B固定	A+CeC+B	C+LT+M-B+A							
iPhone 7	-	Lightning	-	-	-	X-191	X-223	X-128	X-208	X-155	X-156	X-208	X-143	X-121	X-182	X-122	X-194	X-220	X-239	X-245	X-120	X-067-070	X-056	X-104	X-103	X-246	X-255	
iPhone SE	-	Lightning	-	-	-	X-224	X-173	X-210	X-157	X-157	X-158	X-213	X-144	X-131	X-193	X-132	X-243	X-240	X-196	X-146	X-172	X-114	X-113	X-247	X-256			
iPhone 6S	-	Lightning	-	-	-	X-175	X-219	SNA-55	SNA-56	X-145	X-123	X-212	X-132	X-149	X-133	X-215	X-241	X-197	X-147	X-183	X-159	X-154	X-200	X-178	X-248	X-257		
Xperia XZ Premium	sim free G8188	TypeC	○	-	○	X-185	X-236	X-150	X-127	X-250	X-186	X-237	X-151	X-137	X-251	X-177	X-252	X-199	X-260	X-253	X-153	X-198	X-154	X-200	X-178	X-249		
Xperia X	Y-mobile 902SO	TypeC	-	-	○	X-199	X-244	X-206	X-207																			
SHARP																												
Android One S7	Ymobile SHSHG3	TypeC	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Android One S5	S5-SH	TypeC	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Android One S3	S3-SH	TypeC	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Android One S1	Ymobile SHSGG2	microUSB	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Android One	507SH	microUSB	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Android One X4	X4-SH	TypeC	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Android One X1	X1	TypeC	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS Zero	SH-M10	TypeC	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS R2 Compact	SH-M09	TypeC	○	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS sense2	OCN-SH-M08	TypeC	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS sense2	AECN-SH-M08H	TypeC	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS sense2	UQ-SHV43_u	TypeC	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS sense	UQ-SHV40_u	TypeC	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS sense plus	sim free SH-M07	TypeC	○	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS R compact	sim free SH-M06	TypeC	○	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS sense lite	sim free SH-M05	TypeC	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS	Biglobe SH-M04-A	microUSB	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS	美天 SH-M04	microUSB	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS mini	sim free SH-M03	microUSB	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS L	SHV-37	microUSB	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS Xx-Y	404SH	microUSB	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS CRYSTAL Y2	403SH	microUSB	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS CRYSTAL Y	402SH	microUSB	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS PHONE THE PRE	009SHY	microUSB	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
AQUOS PHONE ef	WX05SH	microUSB	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
PANTONE	WX03SH	microUSB	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
かんたんケータイ	WX02SH	Foma	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
PANTONE	WX01SH	Foma	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
KYOCERA																												
Android One S6		TypeC	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Android One S4	S4-KC	TypeC	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Android One S2		microUSB	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Android One X3		TypeC	○	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
かんたんスマホ	705KC	TypeC	○	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
DIGNO A	sim free KYV44	TypeC	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
DIGNO V	sim free KYV42	microUSB	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
DIGNO W	sim free KYV40																											

Zenfone 5	sim free:ZE620KL	TypeC	-	-	○	-	○P	○PD	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	PD	*PD	○	○	○	-	○P	○P	○P	○P	*PD	○
Zenfone 5Q	sim free:ZC600KL	TypeC	-	-	○	-	○P	○PD	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	PD	*PD	○	○	○	-	○P	○P	○P	○P	*PD	○
Zenfone 4 Max	sim free:ZC520KL	microUSB	-	-	-	-	○P	○P	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○P	○P	-	○P	○P	○P	○P	○	○	○		
Zenfone 4 Selfie	sim free:ZD553KL	TypeC	-	-	○	-	○P	○PD	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	PD	*PD	○	○	○	-	○P	○P	○P	○P	*PD	○
Zenfone 4 Pro	sim free:ZS551KL	TypeC	-	-	○	-	○P	○PD	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	PD	*PD	○	○	○	-	○P	○P	○P	○P	*PD	○
Zenfone 4	sim free:ZE554KL	TypeC	-	-	○	-	○P	○PD	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	PD	*PD	○	○	○	-	○P	○P	○P	○P	*PD	○
Zenfone 3 Deluxe	sim free:ZS570KL	TypeC	○	-	-	-	○P	○Q	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○	○	○	○	○	-	○P	○P	○P	○P	○	○
Zenfone 3 Zoom	sim free:ZE553KL	TypeC	-	-	-	-	○P	○P	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○	○	○	○	○	-	○P	○P	○P	○P	○	○
Zenfone 3 Max	sim free:ZC520TL	TypeC	-	-	-	-	○P	○P	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○	○	○	○	○	-	○P	○P	○P	○P	○	○
Zenfone 3 Laser	sim free:ZC551KL	microUSB	-	-	-	-	○P	○P	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○P	○P	-	○P	○P	○P	○P	○	○	○		
Zenfone 3	sim free:ZE520KL	TypeC	○	-	-	-	○P	○Q	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○	○	○	○	○	-	○P	○P	○P	○P	○	○
Zenfone 2	sim free:ZE551ML	microUSB	-	○	-	-	○P	○Q	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○P	○P	-	○P	○P	○P	○P	○	○	○		
Zenfone Go	sim free:ZB551KL	microUSB	-	-	-	-	○P	○P	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○P	○P	-	○P	○P	○P	○P	○	○	○		
Zenfone Max	sim free:ZC550KL	microUSB	-	-	-	-	○P	○P	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○P	○P	-	○P	○P	○P	○P	○	○	○		
Zenfone Max	OCN: M2	microUSB	-	-	-	-	○P	○P	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○P	○P	-	○P	○P	○P	○P	○	○	○		
Zenfone Live	sim free:ZB501KL	microUSB	-	-	-	-	○P	○P	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○P	○P	-	○P	○P	○P	○P	○	○	○		
Zenfone 2 Laser	sim free:ZE500KL	microUSB	-	-	-	-	○P	○P	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○P	○P	-	○P	○P	○P	○P	○	○	○		
Zenfone Max Plus	sim free:M1	microUSB	-	-	-	-	○P	○P	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○P	○P	-	○P	○P	○P	○P	○	○	○		
Nexus 7 2013	google:ME571-16G	microUSB	-	-	-	○	○P	○P	○P	○P	○P	○P	-	○P	○P	○P	○P	○P	○	○P	○P	-	○P	○P	○P	○P	○	○	○			
SAMSUNG																																
Galaxy A30	JCOM:SCV43-j	TypeC	-	-	○	-	○P	○P	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	PD	*PD	○	○	○	-	○P	○P	○P	○P	*PD	○
Galaxy A30	UQ:SCV43-u	TypeC	-	-	○	-	○P	○P	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	PD	*PD	○	○	○	-	○P	○P	○P	○P	*PD	○
GEANEE (ジーーモバイル)																																
イオンスマホ FXC-5A	Aeon:FXC-5A	microUSB	-	-	-	-	○P	○P	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○P	○P	-	○P	○P	○P	○P	○	○	○		
ZTE																																
Libero S10	Ymobile:901ZT	TypeC	-	-	-	-	○P	○P	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○	○	○	○	○	-	○P	○P	○P	○P	○	○
MOTOROLA																																
Nexus 6	google:XT-1100	microUSB	-	○	-	○	○P	○Q	○P	○P	○P	○P	○	-	○P	○P	○P	○P	○P	○	○P	○P	-	○P	○P	○P	○P	○	○	○		
FUJITSU																																
Arrows M04 Premium	simfree/UQ	microUSB	-	-	-	-	○P	○P	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○P	○P	-	○P	○P	○P	○P	○	○	○		
arrows M04	simfree/楽天:M04	microUSB	-	-	-	-	○	○P	○P	○P	○P	○P	○	-	○P	○P	○P	○P	○P	○	○P	○P	-	○P	○P	○P	○P	○	○	○		
arrows M03	simfree:M03	microUSB	○	-	-	-	○P	○Q	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○P	○P	-	○P	○P	○P	○P	○	○	○		
ARROWS RM02	楽天:RM02	microUSB	-	○	-	-	○P	○Q	○P	○P	○P	○P	-	-	○P	○P	○P	○P	○P	○	○P	○P	-	○P	○P	○P	○P	○	○	○		
ARROWS M02	simfree:M02	microUSB	-	○	-	-	○P	○Q	○P	○P	○P	○P	-																			