

更新日 2013年5月27日

Foma: Softbank Wcdma(3G)に使用可

- 適合可
- △ 満充電まで長時間
- X 非適合
- ★ 純正ケーブル/アダプタ使用可

品番	DC充電器 / AC充電器 / USB充電器																USB ポート付	変換ケーブル														
	X-056 X-057	X-054 X-055 X-093 X-097	X-035 X-061 X-099	X-094 X-098 AS-112 AS-095 AS-114 AS-117 AS-175 AS-176 AS-949	非MFI WZ-03 WZ-04 WZ-05	MFI X-066	X-018 X-019 X-020 X-025 X-026 X-036 X-037 X-038 X-039	X-018 X-019 X-020 X-025 X-026 X-036 X-037 X-038 X-039	X-019 X-020 X-025 X-026 X-036 X-037 X-038 X-039	X-020 X-025 X-026 X-036 X-037 X-038 X-039	AS-088 AS-101 AS-103 AS-105 AS-150 AS-904 AS-910 AS-912	AS-914 AS-916 AS-920 AS-927 AS-929 AS-931 AS-933	AS-089 AS-102 AS-104 AS-106 AS-155 AS-905 AS-911 AS-913	AS-915 AS-917 AS-921 AS-928 AS-930 AS-932 AS-934	AS-923	X-049		AS-919 AS-070 AS-058	Foma →micro X-039 au →micro X-040	micro →dock X-048	dock→ lightning WZ-01 micro→ lightning WZ-02	micro→ Foma X-046	micro→ au X-047									
充電端子	単一端子				micro				Foma au dock				単一端子		単一端子		単一端子		PSP型		USB port		単一端子									
端子	micro		dock		lightning		micro		Foma		au		dock		単一端子		単一端子		PSP型		USB port		micro		dock		単一端子		Foma		au	

au

NEC - Smartphone		Japan																											
IS11N	Medias BR (7リットル)	micro	○	○	○	X	X	X	○	X	X	X	X	X	X	X	X	X	X	X	X	X	★	○	X	X	X	X	X

TOSHIBA (富士通/東芝モバイルコミュニケーション) - Smartphone/Tablet		Japan																												
IS12T	Windows® Phone	micro	○	○	○	X	X	X	○	X	★	X	X	X	★	★	X	★	○	X	X	X	X	○	○	X	X	X	X	○
IS11T	REGZA Phone	micro	○	○	○	X	X	X	○	X	★	X	X	X	★	★	X	★	○	X	X	X	X	○	○	X	X	X	X	○
AT500	REGZA Tablet	独自端子	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
IS04	REGZA Phone	micro	○	○	○	X	X	X	○	X	★	X	X	X	★	★	X	★	○	X	X	X	X	○	○	X	X	X	X	○
IS02	Windows® Phone	micro	○	○	○	X	X	X	○	X	★	X	X	X	★	★	X	★	○	X	X	X	X	○	○	X	X	X	X	○

TOSHIBA (富士通/東芝モバイルコミュニケーション) - Win / Cdma one		Japan																												
T008		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
T007		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
T006		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
T005		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
T004	REGZA Phone	au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
T003		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
T002		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
T001	ワルビーナ	au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
TSX06	iida X-RAY	au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
TSX05	iida Light Pool	au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
TSX04	iida PLY	au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
TSX01/02/03	YAYOI KUSAMA	au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
TSY01	biblio	au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W651T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W641T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W631T	sportio	au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W621T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W611T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W561T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W551T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W541T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W531T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W521T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W511T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W471T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W461T	DRAPE	au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W451T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W441T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W431T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W421T	neon	au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W411T	MUSIC-HDD	au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W321T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W311T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W211T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
A5529T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
E08T		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○

FUJITSU - Smartphone		Japan																												
FJL21	Arrows ef	micro	○	○	○	X	X	X	○	X	★	X	X	X	★	★	X	★	○	X	X	X	X	○	○	X	X	X	X	○
ISW13F	Arrows Z	micro	○	○	○	X	X	X	○	X	★	X	X	X	★	★	X	★	○	X	X	X	X	○	○	X	X	X	X	○
ISW11F	Arrows Z	micro	○	○	○	X	X	X	○	X	★	X	X	X	★	★	X	★	○	X	X	X	X	○	○	X	X	X	X	○
IS12F	Arrows ES	micro	○	○	○	X	X	X	○	X	★	X	X	X	★	★	X	★	○	X	X	X	X	○	○	X	X	X	X	○

FUJITSU - Win / Cdma one		Japan																												
F001		micro	○	○	○	X	X	X	○	X	X	X	X	X	X	X	X	X	○	X	X	X	X	○	○	X	X	X	X	○

PANASONIC - Win / Cdma one		Japan																												
P001		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W62P		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W61P		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W52P		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○
W51P		au	X	X	X	X	X	X	X	X	○	X	X	X	○	○	X	★	X	X	X	X	X	○	○	X	X	X	X	○

SONY / SONY-Ericsson - Smartphone/Tablet		Japan																												
SOL22	Xperia UL	micro	○	○	○	X	X	X	○	X	X	X	X	X	X	X	X	★	○	X	X	X	X	○	○	X	X	X	X	○
SOL21	Xperia VL	micro	○	○	○	X	X	X	○	X	X	X	X	X	X	X	X	★	○	X	X	X	X	○	○	X	X	X	X	○
IS12S	Xperia acro HD	micro	○	○	○	X	X	X	○	X	X	X	X	X	X	X	X	★	○	X	X	X	X	○	○	X	X	X	X	○
IS11S	Xperia acro	micro	○	○	○	X	X	X	○	X	X	X	X	X	X	X	X	★	○	X	X	X	X	○	○	X	X	X	X	○

